

Wiring the DEI 507M Tilt Sensor

Wire in relay so that orange wire is grounded when the ignition is off. This powers the tilt sensor so that it properly calibrates.

