





^{**}NOTE: MASTERCELL inputs must be ground switched. Applying 12-volts directly to an input will damage the MASTERCELL and void the warranty.



^{***}NOTE: Front POWERCELL Only Shown for Clarity.