


Wiring a Traditional Cooling Fan



*NOTE: Infinitybox wire Colors & Connector Positions will vary for different kits. See the Configuration Sheet that came with your kit for exact wire colors and locations.



^{**}NOTE: MASTERCELL inputs must be ground switched. Applying 12-volts directly to an input will damage the MASTERCELL and void the warranty.

^{***}NOTE: Front POWERCELL Only Shown for Clarity.