



* Fused +12-Volts Provided through Infinitybox POWERPLUG

Digi-Tails tries to match the original wiring colors in the OEM harness to their wiring. Depending on the kit, wires for the turn signals and running lights may be a different color. See the Digi-Tails manual.

- Digi-Tails Driver Side Tail Lights or Driver Side Turn Signal should connect to LEFT TURN SIGNAL on rear POWERCELL.
- Digi-Tails Passenger Side Tail Lights or Passenger Side Turn Signal connect to RIGHT TURN SIGNAL on rear POWERCELL.
- Digi-Tails Running Lights wire connect to PARKING LIGHT output on rear POWERCELL.

NOTE: Infinitybox wire Colors & Connector Positions will vary for different kits. See the Configuration Sheet that came with your kit for exact wire colors and locations.

NOTE: MASTERCELL inputs must be ground switched. Applying 12-volts directly to an input will damage the MASTERCELL and void the warranty.

NOTE: Some wiring omitted for clarity. See your Infinitybox manual for details.

