


Wiring Uni-Steer Electra Steer Column



* Size the value of this resistor based on the maximum current spec for your LED.

NOTE: Infinitybox Wire Colors & Connector Positions will vary for different kits. See the Configuration Sheet that came with your kit for exact wire colors and locations. Some wires omitted for clarity. Follow the instructions that came with your kit for complete details.

