

Bulkhead Connector
On Firewall

POWERCELL Left Turn Signal Output

POWERCELL Right Turn Signal Output

POWERCELL High Beam Output

POWERCELL Parking Light Output

Dash Ground

LIGHTS

WIPERS

BLOWER

BLEND

TEMP

DEFROST

Left Turn Indicator


High Beam Indicator

Right Turn Indicator

MASTERCELL™
INPUT UNIT

NOTES:

1. Carefully read and understand all instructions and manual for your Infinitybox system before wiring. Contact technical support with questions.
2. Wiring diagrams are intended for reference only. See your manual and specific configuration sheet for proper wire identification.
3. Some wires omitted for clarity. See your manual for details.
4. Wire locations on connectors are for reference only. This diagram does not show specific connector cavities. Contact Infinitybox technical support for details.



INFINITYBOX
INTELLIGENT WIRING

INFINITYBOX, LLC

1979 Jeep CJ7

Dash Lighting

Copyright 2022 Infinitybox, LLC All Rights Reserved.		SIZE C	FSCM NO	DWG NO JEEP 05	REV A
SCALE		N/A		SHEET	1 OF 1